

# HITACHI Camera Accessories

		KP-M1A, M2A, M2R, M3A, M3R	KP-M20 / KP-M30	KP-F30, KP-F33, KP-F80	KP-FB30SCL, KP-FBR30SCL	KP-FD30, KP-FD30M	KP-FD30CL	KP-F30SCL, KP-FR30SCL	KP-F31SCL, KP-FR31SCL	KP-F39SCL, KP-FR39SCL	KP-F80SCL, KP-FR80SCL	KP-F140F, KP-FD32F, KP-FD140F	KP-F33GV, KP-FD33GV	KP-F83GV, KP-FD83GV	KP-F140GV, FD140GV, KP-F145GV	KP-F202GV, KP-FD202GV	KP-F500GV, KP-FD500GV	KP-F100B, F100BCL	KP-F120, KP-F120CL	KP-F120F	KP-FD140SCL, KP-FD500SCL	KP-F145WCL	KP-F200CL	KP-F200SCL, KP-FR200SCL	KP-FM200WCL / KP-FMR200WCL	KP-FD202SCL	KP-F230SCL, KP-FR230SCL	KP-FM400WCL	KP-F500SCL, KP-FR500SCL	KP-D20A, KP-D20B	HV-D27A, HV-37A	HV-D30	HV-F22GV	HV-F202GV	HV-F22F, HV-F31F	HV-F22CL, HV-F31CL	HV-F202SCL	HV-HD30	HV-HD201M							
Power Supplies	45601-C1	R	R	R	R	x	R	R	R	R	R							R	R		R		R	R		R	R		R	x	x	x									x					
	45601-C4	x		x	x		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x																	
	45601-C5	x	x	x			x											x	x	x																										
	45601-C6																																													
	45601-C9	x	x	x																																										
	45601-C15						x																																							
	DV12-C1	R	R	R	R	x	R	R	R	R	R							R	R		R		R	R		R	R		R	x	x	x											x			
	DV12-C4	x		x	x		x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x																
DV12-C7																																												x		
Junction Box	JU-M1A	R			R				R	R	R							R	R		R		R	R		R	R		R																	
	JU-F30		R	R				R																																						
Level Converter	JU-C20																																													
	JU-Z2																																													
Junction Box	C201 KS	R	R	R	R			R	R	R	R						R	R		R		R	R		R	R		R	R		R															
Cables	C501 KS	R	R	R	R			R	R	R	R						R	R		R		R	R		R	R		R	R		R															
	C102 KS	R	R	R	R			R	R	R	R						R	R		R		R	R		R	R		R	R		R															
Remote Head Camera Cables	C-501KAJ																																													
	C-102KAJ																																													
	C-201KAJ																																													
	C-551KHD																																													
	C-102KHD																																													
	C-202KHD																																													
Remote Control Cables	C9D232C-6																																													
	C9D232CF-6																																													
	C-152-RC2																																													
	C-302-RC2																																													
	C-602-RC2																																													
C-103-RC2																																														

R Junction Boxes require a camera cable and a C1 type power supply in order to power the camera.

O Remote Control Units and Level Converters require a cable to work with the camera.

x These items require no additional interface components.



